

BOMBARDIER SEAT COVERS

To place an order please email info@charmans.co.nz or call us on **06 843 6969**.

Please note: Some items are non-returnable. When placing an order, you acknowledge you have read the conditions of the catalogue/sale.



YEAR		DESCRIPTION	CODE
2013	CAN-AM	Can-Am DS 450 XC BLACK	BOM012
2012/2016		Can-Am Commander 800/1000 - CANVAS - BLK*	BOM009C
2012/2016		Can-Am Commander 800/1000 - PVC - BLK*	BOM009P
2012/2016		Can-Am Commander 800/1000 - CANVAS - BLK <i>Seat Cushion Only</i>	BOM009H
2012/2016		Can-Am Commander 800/1000 - PVC - BLK <i>Seat Cushion Only</i>	BOM009H1
		<i>*Seat Cushion & Back Pad</i>	
2016/2020	DEFENDER	Can-Am Defender 800/1000 - Blk Base & Back (SET)*	BOM020
2016/2020		Can-Am Defender 800/1000 - Canvas Blk Base & Back (SET)*	BOM020C
2016/2020		Can-Am Defender 800/1000 PVC - Blk Base & Back (SET)*	BOM020P
		<i>*Please specify if Driver or Passenger Seat is required</i>	
2016/2020	DEFENDER	Can-Am Defender 800/1000 - BLK <i>Centre seat</i>	BOM021
2016/2020		Can-Am Defender 800/1000 - CANVAS - BLK <i>Centre seat</i>	BOM021C
2016/2020		Can-Am Defender 800/1000 - PVC - BLK <i>Centre seat</i>	BOM021P
2019	DEFENDER	CAN AM Defender XMR HD10 - CANVAS - BLK (Back & Base)	BOM025C
2019		CAN AM Defender XMR HD10 - PVC - BLK (Back & Base)	BOM025P
2004/2016	OUTLANDER	Outlander 400 Can-Am - BLK	BOM006
2004/2016		Outlander 400 Can-Am - CANVAS - BLK	BOM006C
2004/2016		Outlander 400 Can-Am - PVC - BLK	BOM006P
2006		Outlander 330 & 400 / Outlander Max 400 - BLK	BOM002*
2006		Outlander / Outlander Max - CANVAS - BLK	BOM002C
2006		Outlander / Outlander Max - PVC - BLK	BOM002P
2006		Outlander - Pillion Seat - BLK	BOM003
2006		Outlander - Pillion Seat - CANVAS - BLK	BOM003C
2006		Outlander - Pillion Seat - PVC - BLK	BOM003P
2006		Outlander - Back Pad - BLK	BOM004
2006		Outlander - Back Pad - CANVAS - BLK	BOM004C
2006		Outlander - Back Pad - PVC - BLK	BOM004P
2006/2012		Outlander & Max 650 VINYL - BLK Back Seat Only	BOM011
2006/2012		Outlander & Max 650 CANVAS - BLK <i>Back Seat Only</i>	BOM011C
2006/2012		Outlander & Max 650 PVC - BLK <i>Back Seat Only</i>	BOM011P
2006/2012		Outlander & Max 500/650/800 - BLK	BOM005
2006/2012		Outlander & Max 500/650/800 - CANVAS - BLK	BOM005C
2006/2012		Outlander & Max 500/650/800 - PVC - BLK	BOM005P

BOMBARDIER SEAT COVERS

To place an order please email info@charmans.co.nz or call us on **06 843 6969**.

Please note: Some items are non-returnable. When placing an order, you acknowledge you have read the conditions of the catalogue/sale.



YEAR		DESCRIPTION	CODE
2013/2019		Outlander & Max 500/650/800/1000XT Can-Am - BLK	BOM008
2013/2019		Outlander & Max 500/650/800/1000 XT Can-Am - CANVAS - BLK	BOM008C
2013/2019		Outlander & Max 500/650/800/1000 XT Can-Am- PVC- BLK	BOM008P
2006/2012		Outlander Max 550-1000 - VINYL - BLK (<i>Back Rest</i>)	BOM013
2006/2012		Outlander Max 550-1000 - CANVAS - BLK (<i>Back Rest</i>)	BOM013C
2006/2012		Outlander Max 550-1000 - PVC - BLK (<i>Back Rest</i>)	BOM013P
2013		Outlander G2 500/650/800/1000XT - BLACK	BOM113
2013		Outlander G2 500/650/800/1000XT - CANVAS - BLK	BOM113C
2013		Outlander G2 500/650/800/1000XT - PVC - BLK	BOM113P
2014/2015		Outlander Max - Vinyl - BLK (<i>Back Seat</i>)	BOM014
2014/2015		Outlander Max - Canvas - BLK (<i>Back Seat</i>)	BOM014C
2014/2015		Outlander Max - PVC - BLK (<i>Back Seat</i>)	BOM014P
2014/2015		Outlander Max - VINYL - BLK (<i>Back Rest</i>)	BOM015
2014/2015		Outlander Max - CANVAS - BLK (<i>Back Rest</i>)	BOM015C
2014/2015		Outlander Max - PVC - BLK (<i>Back Rest</i>)	BOM015P
2016/2020		Outlander 450/570/800 - THATCH VINYL - BLK	BOM022
2016/2020		Outlander 450/570/800 - CANVAS - BLK	BOM022C
2016/2020		Outlander 450/570/800 - PVC - BLK	BOM022P
2006/2009	RENEGADE	Renegade 500 / 800 Can-Am - BLK	BOM010
2006/2009		Renegade 500 / 800 Can-Am - CANVAS - BLK	BOM010C
2006/2009		Renegade 500 / 800 Can-Am - PVC - BLK	BOM010P
1998/2005	TRAXTER	Traxter 500 Foot Shift - BLK	BOM001*
1998/2005		Traxter 500 - CANVAS - BLK	BOM001C
1998/2005		Traxter 500 - PVC - BLK	BOM001P
2003	QUEST	Quest 500 - BLK	BOM007
2003		Quest 500 - CANVAS - BLK	BOM007C
2003		Quest 500 - PVC - BLK	BOM007P